

## RQ-BK-3 Installation Instructions



Step 1 - Insert (3) Rubber Grommets into headlight assembly

Step 2 - Insert (3) Grommet Sleeves - Note the direction of the sleeve above with RED arrows

Step 3 - Insert (1) M6 x 25mm bolt thru Bracket B and secure with M6 nylon nut  
- Note the direction of the bolt above with BLUE arrow

Step 4 - Insert (1) M6 x 30mm bolt thru Bracket A and secure with M6 nylon nut  
- Note the direction of the bolt above with YELLOW arrow

Step 5 - Secure assembly to frame with (2) M6 x 30mm bolts  
- Note the direction of the bolt above with GREEN arrow

SEE PICTURES ON PAGE 2 FOR INSTALLATION REFERENCE

RQ-BK-3 Installation Instructions

