


RQ-HARN-8 Installation Instructions



Connector 1 - Connect to desired ACC.

Connector 2 - Connect to RQ-HARN-1 ACC output.

Connector 3 - Connect to 12v battery ground - terminal.

Connector 4 - Connect to 12v battery positive + terminal.

Fuse - 7.5a

Relay - Modern silent type relay. You will not hear click.